

Features of Your Remote Control

To use most of the features described in this section, make sure you are in **SAT** mode by pressing the **SAT Mode** button

Note: To control a TV, VCR, or other available component, the remote must be programmed. See the User's Guide for details.

SAT Mode
Press to control your satellite receiver, TV power, volume and mute

TV Mode
Press to control your TV

VCR Mode
Press to control your VCR

AUX Mode
Press to control other components such as a DVD player

Recover
Recovers satellite programming if your TV input or channel has changed

Receiver Power & TV Power
Left button turns the receiver on/off, right button turns the TV on/off

Menu
Access receiver features and settings

Themes
Search for programs using Themes

Recall
Go back to last channel viewed

Info
Display program information

DISH
Explore interactive TV features

Number Buttons
Enter a channel number or navigate through menus

Search
Search for a program

Page Buttons
Page up/down in menus and program guide

Program Guide
Display current and future satellite program listings

Arrows/Select Buttons
Channel up/down, navigate through menus/guides and select options

Browse
See what is on other channels while watching TV

View Satellite Program
Exit any menu/guide and go back to watching a program

Device Codes:

TV: _____ 1*
(optional)

VCR: _____ 1*
(optional)

AUX: _____ 1*
(optional)

My remote is programmed in Limited Mode (check box):

***Tip:** Using the Limited Mode option (adding "1" when programming the remote) helps prevent you from accidentally tuning to a TV or VCR channel (or input) that does not display satellite TV programming. See User's Guide for details.

Watching Your Satellite Programs

To operate your satellite receiver you must be in **SAT** mode by pressing the **SAT Mode** button



Turns the Satellite Receiver On or Off

Turns the TV On or Off

Easy Ways to Find a Program

Select a program from the Program Guide

GUIDE

OR

Channel Up/Down one program at a time

OR

Enter a channel number from the Channel Directory

Note: If you select a future program, you will have the option to set up a timer.

Pressing the **GUIDE** button repeatedly cycles through your Favorites Lists (see User's Guide).

Tip: You can skip ahead or back in the Program Guide several hours at one time. Enter the number of hours you want to skip using the Number buttons, then press the **RIGHT** (or **LEFT**) **ARROW** button to move forward (or back).



Tip: While viewing a program, press the **BROWSE** (**RIGHT ARROW**) button. Then press either the **UP** or **DOWN ARROW**. The information on other channels appear in the Browse Banner. Press **SELECT** to watch the program.



Tip: Press the **THEMES** (**LEFT ARROW**) button to bring up the Theme Categories menu which allows you to search for a program based on its content (for example, by movies, sports, etc.).

