

Features of Your Remote Control 1

To use the features described in this section, make sure you are in SAT mode by pressing the SAT Mode button

Note: To control a TV, VCR, or other available component, the remote must be programmed. See the User's Guide for details.

- SAT Mode**
Press to control your satellite receiver, TV power, volume and mute
- TV Mode**
Press to control your TV
- VCR Mode**
Press to control your VCR
- AUX Mode**
Press to control other components such as a DVD player
- Receiver & TV Power**
Top button turns the receiver on/off, bottom button turns the TV on/off
- Menu**
Access receiver features and settings
- Themes**
Search for programs using Themes
- Recall**
Go back to last channel viewed
- Info**
Display program information
- VCR Buttons**
Operates some VCR or DVD players (in VCR or AUX Modes)
- Recover**
Recovers satellite programming if your TV input or channel has changed
- Picture-In-Picture (PIP) Buttons**
Watch two separate programs at once (in Single Mode)
- Format**
Changes the picture to the desired width to match the program you are viewing
- Page Buttons**
Page up/down in menus and display options
- Program Guide**
Display current and future satellite program listings
- Arrows/Select Buttons**
Channel up/down, navigate through menus/guides and select a desired option
- Browse**
See what is on other channels while watching TV
- View Satellite Program**
Exit any menu/guide and go back to viewing live TV
- DISH**
Explore interactive TV features
- Number Buttons**
Enter a channel number, or select menu items
- Search**
Search for a program
- Remote Key**
Green with number 1 indicates TV1
Blue with number 2 indicates TV2

Device Codes:

TV: _____ VCR: _____ AUX: _____

My remote is programmed in Limited Mode (check box):

Tip: Using the Limited Mode option helps prevent you from accidentally tuning to a TV or VCR channel (or input) that does not display satellite TV programming.

How to Watch TV on TV1 1

TV1 viewing location is identified with a green key on your remote and the green TV1 logo on the TV screen



To watch satellite TV or if you lose video:

Set TV to _____ (Input)

Watching Your Satellite Programs

To operate your satellite receiver you must be in SAT mode by pressing the SAT Mode button



Turns the Satellite Receiver On or Off
Turns the TV On or Off

Easy Ways to Find a Program

Select a program from the Program Guide



OR

Channel Up/Down one program at a time

OR

Enter a channel number from the Channel Directory

Program Guide Channel Color Key

- Blue - Satellite Programming
- Yellow - Digital Off-Air Programming (off-air antenna required)
- Red - Call to order this channel
- Green - Use your remote to order this channel



Enhance Your TV Experience

Tune to DISH Network
FYI Channel 101

dishnetwork.com

Press DISH button and select Service

See the User's Guide

