

Finding Programs On Satellite TV

Make sure your remote is in SAT mode by pressing the **SAT Mode** button



Three easy ways to find the program you want to watch

1. Use the **UP/DOWN ARROW** buttons to change the channel up or down one channel at a time



OR

2. Use the Number buttons to enter a channel number



OR

3. Use the **GUIDE** button to display the Program Guide

GUIDE



The Program Guide shows you current and future program listings.



Then...

Use the **ARROW** or **PAGE UP/DOWN** buttons to highlight a program and then press the **SELECT** button



Tip: HD programs can be found between 9420-9499 in the program guide.

Note: If you select a program that is not currently broadcasting, you will have the option to set up a timer.

Pressing the **GUIDE** button repeatedly cycles through your Favorites Lists (see *User's Guide*).

Tip: To skip ahead a specific amount of hours in the guide, enter the number of hours with the number buttons, then immediately press the **RIGHT ARROW** button. For example, pressing the 3 button then the **RIGHT ARROW** will move ahead 3 hours in the guide.

Tip: While viewing a program, press the **BROWSE** (**RIGHT ARROW**) button. Then press either the **UP** or **DOWN ARROW**. The information on other channels appear in the Browse Banner. Press **SELECT** to watch the program.



Tip: Press the **THEMES** (**LEFT ARROW**) button to bring up the Theme Categories menu which allows you to search for a program based on its content.



Quick Help and Tips



What should I do if I have a snowy picture (or a blue or black screen)?

Check to make sure your HDTV is tuned to the correct input. You may need to cycle through your available inputs using the SD/HD INPUT button. Confirm your resolution setting matches what is written in the *Watching Satellite/HD Programming* section of this guide.



What is the PIP button for?

This feature does not apply to your receiver, but can be used with some TVs with this feature.



What should I do if my remote control doesn't seem to operate my satellite receiver?

- Try pressing the SAT Mode button.
- Make sure the remote UHF antenna is attached to the back of the receiver.
- Your remote control batteries may need to be replaced (alkaline batteries are recommended).
- Check the remote address (see *User's Guide*).



Why does my receiver change channels and do things on its own?

You may have a neighbor that also has a UHF remote and their remote may be controlling your receiver. This is easily corrected by changing your remote control address. See your *User's Guide* for instructions.



What would affect my satellite signal?

There may be obstructions in front of your satellite dish. Sometimes new tree or plant growth can obstruct the signal between the satellite and the dish. If you are experiencing frequent signal interruptions, leave your TV on and press the SYSTEM INFO button on the front of the receiver. Contact Customer Service using the phone number shown on the System Information screen.



What are the benefits of my satellite receiver being connected to a telephone line?

Keeping your phone line connected to the receiver enables you to take advantage of interactive TV services, Customer Support, or Caller ID. It will also allow you to use your remote control to order Pay-Per-View events or movies.



Why does my High Definition picture seem distorted?

You may need to adjust the format of the picture to match the program you are viewing. Press the FORMAT button on your remote to cycle through the available picture formats.



Why don't some programs on high definition channels look like high definition?

Some programming on high definition channels was originally produced before high definition technology. Therefore, these programs will be displayed in a lower resolution.



Why don't all of my channels show up on the Program Guide when I browse?

You may have a Favorites List active that does not include those channels. Repeatedly press the GUIDE button and cycle through the Favorites Lists until you find a list that contains those channels. Also check to see if those channels are locked (see *User's Guide*).



Can the Program Guide display program information for my off-air local channels?

For information to be displayed, you must subscribe to the DISH Network local programming package (if available).



Tip: To ensure your receiver has the latest program guide information and the latest software updates, press the **POWER** button to turn your receiver off when not in use.

Tip: Some receiver problems can be solved by pressing and holding the **POWER** button on the front of the receiver for about 10 seconds until the green light goes out. After releasing the **POWER** button, the receiver will return to normal operation within a few minutes.

QUICK REFERENCE GUIDE

High Definition Satellite Receiver

Look inside for important tips to operate your satellite receiver



Channel Directory

Note: All programming subject to change without notice. Go to dishnetwork.com for a current directory.

		Indicates HD channels			
A&E	118	Film Fest HD	9480	QVC	226
ABC Family	180	Fine Living	113	Rave HD	9470
AMC	130	Food Network	110	Research TV	9400
America's Preview Channel	231	Fox Movie Channel	123	Resort & Residence Channel	216
Angel One	262	FOX News Channel	206	RFD-TV	9409
Animal Planet	184	Fox Reality	190	Rush HD	9476
Animania HD	9474	Fox Soccer	149	SCI FI Channel	172
BBC America	135	Free Speech TV	9415	Science Channel, The	193
Beauty & Fashion Channel	225	Fuse	159	Shop at Home	224
BET	124	FX 4	137	ShopNBC	223
Biography Channel, The	119	G4	191	SI TV	159
Bloomberg Businessweek	203	Galavision	833	SOAPnet	188
Boomerang	175	Galaxy HD	9472	SPEED	150
Bravo	129	GamePlay HD	9485	Spike TV	185
BYTV	9403	GO! TV	207	Style	115
Cartoon Network	176	Golf Channel, The	401	TBN	250
CCTV-9	265	Great American Country (GAC)	167	TBS 4	139
CCTV-EAF	884	GSN	116	TeleFutura (East)	830
CMT	166	Hallmark Channel	155	TeleFutura (West)	831
CNBC	208	HDNet	9422	Tennis Channel, The	400
CNBC World	207	HDNet Movies	9423	The Movie Channel (West) 4	320
CNN	200	HDNews	9482	The Movie Channel xtra (West) 4	330
CNN Headline News	202	Healthy Living Channel	223	TLC	183
Colours TV	9407	HGTV	112	TNT 4	138
Comedy Central	107	History Channel, The	120	TNT Disney 4	9420
Court TV	204	History International	121	Toon Disney 4	174
C-SPAN	218	HITN	843	Travel Channel	215
C-SPAN2	212	HorseRacing TV	404	Treasure HD	9473
CSTV	152	HSN	222	Turner Classic Movies	132
Discovery Channel	182	iDive TV	217	Turner South	437
Discovery HD Theater	9421	Independent Film Channel (IFC)	131	TYG	406
Discovery Health	189	International Music Feed	157	TV Guide Channel	102
Discovery Home	194	iShop	229	TV Land	106
Discovery Kids	179	Jewelry Television	227	TV Outlet Mail	219
Discovery Times	192	KBS World	704	Ultra HD	9478
DISH Network PPV in HD	9487	Kung Fu HD	9479	Universal HD	9427
Disney Channel (East)	172	Lifetime	153	University of California TV	9413
Disney Channel (West)	173	Lifetime Movie Network	109	University of Washington TV	9404
DIY	111	Linkmedia	9410	Univision (East)	827
Documentary Channel	197	Men's Channel, The	218	Univision (West)	828
E! Entertainment Television	114	Military Channel	195	USA Network	105
Encore (West) 4	341	NBA HD	343	VH1	182
Encore Action	343	NSNBC	309	VH1 Classic	183
Encore Drama	345	MTV	160	WE: Women's Entertainment	128
Encore Love	346	MTV2	161	Weather Channel, The	214
Encore Mystery	344	mun2	838	WGN	239
Encore Warm	347	NASA	213	World Cinema HD	9475
Encore Westerns	342	National Geographic Channel	186	WorldSport HD	9477
Equator HD	9471	NFL Network	154		
ESPN	140	Nickelodeon Games & Sports	177	ADDITIONAL CHANNELS	
ESPN HD	9424	Nickelodeon/Nick at Nite (East)	170	Audible Music Channels	923-981
ESPN2	144	Nickelodeon/Nick at Nite (West)	171	DISH Network Pay-Per-View	455-539
ESPN2 HD	9425	Nicktoons Network	178	Local Channels	3000-3918
ESPN Classic	143	NOGGIN/The N	169	Regional Sports Networks	409-438
ESPNEWS	142	Northern Arizona University	9411	SIRIUS Music Channels	6001-6116
ESPNU	148	Outdoor Channel, The	153		
EWTV	261	Oxygen	127	DISH HD BRONZE Entertainment Package	
Family Room HD	263	PAX TV	151	DISH HD SILVER Entertainment Package	
				DISH HD GOLD Entertainment Package	

1. Available only to select all DISH Network customers. CCTV channels require DISH 800, DISH 1000 or SuperDISH antenna. KBS World requires SuperDISH antenna pointed at 121° orbital location and subscription to qualifying time zone. Additional fees may apply for selected DISH Network customers to upgrade their dish antenna. 2. DISH Network PPV requires a valid time zone. 3. TeleFutura East is available to customers in the Eastern and Central time zones. TeleFutura West is available to subscribers in the Mountain and Pacific time zones. 4. Available in Georgia, Mississippi, Louisiana, Tennessee and sections of HD programming requires HD television and receiver (HD or VCP receiver, depending on HD channel). DishHD Platinum includes DishHD GOLD package plus all other premium movie packages and NBA TV channel 452.

Movie Packages

HBO	Starz (East) 4	350	SHOWTIME UNLIMITED
HBO (East) 4	Starz (West) 4	351	FLX
HBO (West) 4	Starz Cinema (East) 4	353	The Movie Channel (East) 4
HBO (East) 4	Starz Cinema (West) 4	354	The Movie Channel xtra (East) 4
HBO2 (West) 4	Starz Kids & Family 4	356	Showtime 300 4
HBO Comedy 4	Starz Edge 4	352	Showtime (East) 4
HBO Family 4			Showtime (West) 4
HBO Latino	CINEMAX		Showtime Beyond 4
HBO Signature 4	StarMax 4	314	Showtime Extreme 4
HBO HD	StarMax 4	313	Showtime Showcases 4
	Cinemax (East) 4	319	Sundance Channel
	Cinemax (West) 4	311	Showtime HD
STARZI	Moramax 4	312	
Starz InBlack 4			
Encore (East) 4			

4. FREE Spanish audio feed available. Audio depends on equipment. HD movie Showtime packages with exception of DishHD Platinum package. HBO movie package or Showtime movie package. HD programming requires HD television and receiver (HD or VCP receiver, depending on HD channel).