



## Model 2700/2800/3700 W/VCR Coax Cable Connections

**NOTE:** The devices shown below are for EXAMPLE ONLY.



**NOTE:** Keep the VCR tuned to channel 3 or 4 to match the receiver.

