

Model 3000 W/VCR RCA Cable Connections


NOTE: The devices shown below are for EXAMPLE ONLY.

Receiver To Outlet
Power Cable

1

Receiver To Dish
RG6 Cable

3




Receiver To VCR
RCA Cable

4

Receiver To Phone Outlet
Phone Cord

6



VCR To TV
RCA Cable

5

