



DISH 351 W/VCR Coax Cable Connections

NOTE: The devices shown below are for EXAMPLE ONLY.



NOTE: Keep the VCR tuned to channel 3 or 4 to match the receiver.

VCR To TV
RG6 Cable 4



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
AVIS: RISQUE DE CHOC ELECTRIQUE-NE PAS OUVRIR

U.S. PATENTS: 4627824, 4577716, 4613386, 5599922, 5602844, 6067856, AND 6114147 MAY APPLY TO THIS PRODUCT.
BORN IN AUSTRALIA. ENGINEERED IN AUSTRALIA.
©1999 DISH NETWORK. ALL RIGHTS RESERVED.
310000010001 OF 12/99A YAM

Dolby®
Digital
OUTPUT