DISH 311 W/VCR S-Video Cable Connections