DISH 381 RCA Cable Connections

NOTE: The devices shown below are for EXAMPLE ONLY.