DISH 721 W/VCR RCA Cable Connections